



In order to avoid over-tightning thumb screws to prevent motor from dislocating, drill two screw fixing holes on the side of the boat according to the positions of the two screw holes on the left and right of the bracket (pictured on the left), and fix them with screws.